


Disposition par défaut des notes de la carte 42 version 05-2019

Numéros midi sur le connecteur

Extrémité nappe



12V	12V
nc	nc
nc	nc
nc	nc
49	Do#2
nc	nc
nc	49
nc	51
nc	52
89	54
88	56
87	58
85	59
63	61

72	Do4
73	Do#4
71	Si3
74	Ré4
70	La#3
75	Ré#4
69	La3
76	Mi4
68	Sol#3
77	Fa4
67	Sol3
78	Fa#4
66	Fa#3
79	Sol4
66	79
65	80
65	80
12V	12V
64	81
62	82
60	83
57	84
55	86
53	nc
50	nc
48	nc

12V	12V
49	Do#2
nc	nc
nc	nc
nc	nc
nc	49
nc	51
nc	52
89	54
88	56
87	58
85	59
63	61
58	La#2
85	Do#5
59	Si2
63	Ré#3
61	Do#3
72	Do4
73	Do#4
71	Si3
74	Ré4
70	La#3
75	Ré#4
69	La3
76	Mi4
68	Sol#3
77	Fa4
67	Sol3
78	Fa#4
66	Fa#3
79	Sol4
66	79
65	80
65	80
12V	12V
64	81
62	82
60	83
57	84
55	86
53	nc
50	nc
48	nc
64	Mi3
81	La4
62	Ré3
82	La#4
60	Do3
83	Si4
57	La2
84	Do5
55	Sol2
86	Ré5
53	Fa2
nc	nc
50	Ré2
nc	nc
48	Do2
nc	nc